

## Serene Model 2026/7

# Operating & Installation Manual

Heating Panel with  
24/7 LCD Programming



# Introduction

## Serene Heating Panels

Serene Convection Heating Panels are available as vertical and horizontal models, providing you with the opportunity to choose a model that will optimise the available wall space. Our new designs have passed rigorous testing and quality assurance controls with both style and safety in mind. As a result, they have a slim profile, operate silently, are double insulated, include auto reset overheat protection and are supplied with wall mounting brackets for simple installation.

These Serene Model 2026/7 convection Heating Panels incorporate a fully programmable real time electronic controller with manual override and ECO program - which enables simple easy real time programming and operation 24/7.



## Safety Information:

**This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.**

When using any electrical appliance, safety precautions should always be observed.

**Read these instructions carefully, and retain for future reference.**

When used by, or near, young children or infirm persons, supervision is necessary.

Young children should be supervised to ensure that they do not play with the appliance.

Use this appliance only with the voltage(s) specified on rating label.

Do **NOT** use this appliance other than for its intended use.

Do **NOT** touch hot surfaces or moving parts.

Do **NOT** cover the grilles or place any object or material up against the unit, as this may block entry or exhaust of the airflow.

Do **NOT** probe any opening to remove fluff. To ensure trouble free performance it is recommended that on a regular basis the unit be isolated from the power supply and a vacuum cleaner used remove dust and fluff from the inlet and outlet grilles.

### **Caution:**

When the heater is operated ensure the heater is not obstructed in any way by furniture or drapes etc.

Ensure the heater can operate safely, should the heater switch on when the ambient temperature drops, or a timer activates the heater.

Do **NOT** allow the supply cord to come into contact with heated surfaces during operation.

Regulations require that electrical work be carried out by authorised persons. For your own safety and that of others, ensure this is done.

If the supply cord becomes damaged, it must be replaced by a qualified person in order to avoid any hazard.

## Safety Cutout:

Serene Convection heating panels are fitted with an auto-reset thermal cutout. This safety device will automatically switch off the elements should the heater reach an abnormal temperature.

Should this occur: switch off the heater immediately and allow the heater to cool-down? Overheating is normally caused by blockage of the air vents or by the vents being covered.

NEVER COVER THE HEATING PANEL OR ANY OF THE VENTS. To clean the vents use a vacuum cleaner as necessary

## Connection Details:

The heater is supplied with a flex and 3 pin plug. For single operation the heater can be plugged directly into a socket outlet.

For permanent connection to fixed wiring, the plug must be removed. If the pilot wire is to be used, it must be connected to a separate pilot wire circuit. The black pilot wire **MUST NOT** be connected to Earth. Ensure the power supply to the pilot wire and the mains power to the heater, is disconnected before any servicing or maintenance is carried out.

When permanently wired, and the pilot wire is not being used, the pilot wire must be connected to a potential free terminal in a switched permanent connection unit.


## Installation:

This appliance must be installed in accordance with the current electrical wiring rules and regulations. The heater must not be located immediately below a socket-outlet. A suitable disconnection device (acting in all active supplies) is required to be incorporated in the fixed supply wiring. When used as a bathroom, the heater must be installed such that the controls cannot be touched by a person in the bath or shower.

The minimum required distance from the heater to any floor is 150mm. The minimum required distance from the heater to any adjacent wall is 200mm.

# Operation & Functions

## Guide to the control panel



**1: Power On/Off**

**2: Manual or programmed mode**

**3: Program**

**4: Confirm**

**5-6: Temperature adjustment**

**7: ECO**

**8: Power indicator**

**9: Day of the week**

**10: Heating indicator**

**11: Low power setting**

**12: High power setting**

**14: Manual control**

**15: Automatic control**

**16: Timer**

**17: Hour**

**18: Minute**

**19: Real time temperature**

**20: Temperature (°C)**

## Program set up:

### Power on/off

When the unit is connected to power there is a short buzz, the blue power indicator (8) lights and the LCD display will light for 12 seconds. Pressing the 'Power On' button **(1)** turns the heater on and the day, time and room temperature are displayed.

Then select HI or LO temperature setting by touching ECO **(7)**.

### Manual" or programmed operation

#### Select using **(3)**.

The setting temperature is factory set at 24C.

The program memory is held in the event of any power interruption.

### Time setting

When setting up the program for the first time the actual time needs to be set up as follows.

**Day:** With the power on press **(3 and 4)** at the same time for 3 seconds. The day **(9)** will flash.

Press **(5 and 6)** to select the day and press **(3)** to finish.

**Hour:** The hour indicator **(17)** will be flashing, Touch **(5 or 6)** to set the hour and press **(3)** to finish.

**Minute:** The minute indicator **(18)** will be flashing. Touch **(5 or 6)** to set the minute and touch **(3)** to finish.

**Seconds:** **(19)** will be flashing, Press **(5 or 6)** to set the seconds and press **(3)** to finish.

After setting the seconds the controller will revert back to the day setting as a cycle. Touch button **(4)** to finish time setting.

**All time symbols will now stop flashing.**

# Mode Timer Programming

## 1. Day setting:

Press **(2)** and choose automatic mode display then press **(3)** and the current day on the screen.

**(9)** will be flashing

Touch **(5 or 6)** to set the day and **(17 and 18)** will display the timer for last setting. Press **(3)** to finish.

## 2. Timer setting:

**(19)** will display. Number 1 indicates that the heater is on the first running time.

**(17 and 18)** will display the current setting times, and **(17)** will flash.

Touch **(5 or 6)** to set the desired time (hour) for the program to begin.

Touch **(3)** to confirm this time. **(18)** will begin to flash.

To adjust the time touch **(5 or 6)** then touch **(3)** to confirm, The first running time is now set. **eg. 7-10 am.**

Now **(19)** display will show 2, indicating the second running time.

Repeat the above settings to set a second running time and so on.

Touch **(4)** to finish the timer setting.

## Notes:

- Hours only can be set.
- The setting program will only save after you have touched the **(4)** button.
- The factory pre-setting running time is 07-11 ; and 13-18hours.
- When in automatic mode **(16)** will not display.
- Your Serene Heating Panel is fitted with a 24 hour clock.

## Mode Timer Programming (cont.)

### 3. Setting the running time for one week:

To set the running times set for one day to apply to the remaining days of the week do as follows:

After setting the running times for the first day hold down **(4)** for 5 seconds (this must be done before using **(3)** to confirm the last running time of the day).

In order for the running times to repeat for the whole week (Monday to Sunday) Monday must be set first.

#### Example:

If Monday running times are set 08-12 & 13-17 and you want to repeat these daily, follow the above instructions and the times will then repeat every day unless changed.

#### Notes

Monday MUST be the only start day used or the settings will NOT be repeated for all days of the week.

If you wish to change a single day or multiple days running after setting up an entire week this must be done manually by selecting the desired day(s) by following the normal programming process in section **(2)**.

(Useful for weekends if requiring different running times)

### 4. After setting the running program:

Touch **(4)** to save and the heater will operate in accordance to the programmed settings.

#### Manual timer setting for the current day

Touch **(2)** selects Manual mode.

Touch **(3)** to set the timer and **(17)** will flash

Then touch **(5 or 6)** to adjust the hour.

Touch **(3)** again to set the minute and touch **(4)** to confirm.

The timer **(16)** will light up if the setting time is more than the current time

**Note:**

If **(3)** is touched when setting the minute this will cancel the timer setting.

To turn the heater off touch the power button **(1)**

**Selecting Eco or High power**

Touch **(7)** to choose high/low power,  
If high power is selected, **(12)** will light up.  
If ECO is selected **(11)** will light up.

**Manual or Programmed mode selection:**

Touch **(2)** to select the required mode.  
If manual mode is selected **M** will display and **A** when in programmed mode.

**Memory function after shut down**

The program setting when the unit is turned on again will be as the last setting.

**Electronic locking**

When power is on touch **(5 and 6)** at the same time for **3 seconds** and all control functions will be locked and will be displayed on **(19)** as a square for 5 seconds and then change to real temperature display.

**Methods to unlock:**

- ① No electric supply to the device
- ② Timer over
- ③ Touch **(5 and 6)** at the same time for 3 seconds.

**NOTE**

The program memory is retained in the event of any power interruption.

**Over heat protection:**

All Serene Heating Panels are equipped with a overheat protection switch that will automatically turn the heater off if for any reason the unit has overheated.

The heater will automatically come back on when it has cooled down.

## **Cleaning:**

The heater requires regular cleaning to ensure trouble free operation.

- Isolate the heater from the mains power supply.
- Use a damp cloth to clean the exterior of the heater. Do not use any abrasive cleaners.
- Use a vacuum cleaner to remove dust and fluff visible on the heater inlet and outlet grilles.

Ensure the heater is dry before turning the mains power supply to the heater back on.

## **Wall Mounting Instructions**

The heater is fixed on the wall with the mounting bracket attached to back of the heater.

### **To secure mounting bracket to the wall**

- Remove the wall mounting bracket from the back of the heater, by compressing the fittings at the top and/or sides of the bracket, which clip into the heater body.
- Place the mounting bracket against the wall, ensuring the bracket is level and the minimum distance between the heater and the adjacent surfaces are adhered to
- Mark and drill the fixing holes at the top and bottom of the mounting bracket, and attached to the wall with suitable screws and/or wall anchors).
- Locate the heater over the bottom clips of the wall bracket and then push the heater securely into the fittings on the top and/or sides of the bracket.

### **To remove heater from the wall**

- Using a pointed tip screwdriver, push in and lever out the fittings at the top and/or sides of wall mounting bracket.
- Lift the heater up and away from the wall.

## Wall mounting (cont)

### Important:

- The heater must be mounted a minimum distance of 150 mm from floor level
- 250 mm from adjacent walls
- 500 mm between the heater and any objects heated below it.

**The heater must NOT be located immediately below a socket outlet or within reach of a bath or shower.**

## Specifications:

### Serene S2026/7

**Model S2026**      Power: 1000W/500W  
Dimensions (mm): W 460 D 75 H 400

**Model S2027**      Power 2000W/1000W  
Dimensions (mm): W 830 D 75 H 400

### Electrical Supply:

230-240 volts A.C. 50 Hz

### Wattage:

500W-2000W

### Wiring:

Permanent connection or by cord set.  
Double insulated, no earth required.

**Ingress Protection Rating:**      IP24

**Serene Industries Limited reserves the right to alter specifications without notice.**

## **Contacts:**

### HONG KONG

Head Office - Serene Industries Limited

t: +852 2325 3209

f: +852 2325 3166

e: [info@serene-ind.com](mailto:info@serene-ind.com)

w: [www.serene-ind.com](http://www.serene-ind.com)

Suite 1010, 15F, Block A, Alexander Industrial Building, 62  
King Lam Street,  
Cheung Sha Wan, Kowloon Hong Kong SAR

### NEW ZEALAND

t: (+) 64 (3) 344 5550

f: 0800 437 264- Freefax

e: [nzenquiry@sereneind.com](mailto:nzenquiry@sereneind.com)

w: [www.serene-ind.com](http://www.serene-ind.com)

PO BOX 33501, Barrington, Christchurch 8024

### AUSTRALIA

t: + 61 (3) 8354 4133

f: + 61 (3) 9699 6422

fp: +1800 561 961- Freephone

e: [enquiries@serene-australia.com](mailto:enquiries@serene-australia.com)

w: [www.serene-australia.com](http://www.serene-australia.com)

Suite 201 / 175B Stephen Street, Yarraville  
Melbourne VIC 3013