



## SILVERLEAVES 3 PCE RESIN WICKER BENCH SETTING


## **Assembly Instruction**

Item number:3192437







Step 1: Secure the table frame (B) to the table legs (A), using the bolt (D), washer(G), bolt cover(F) and Allen key(H). Repeat for each leg.




Step 3: Use scissors to carefully cut and remove the strapping securing the glass in place.




Step 4: Carefully lift the glass top and place on a clean protected surface.




Step 5: Using the bolt(E) ,washer(G) with the shaft sleeve,secure with the table frame(A)and leg frame(B),and using the allen key (H).



Step 6: Carefully replace the glass (I) back on top of the table frame (A).




Step 7: Your table is now fully assembled and ready for use.





## Important Notice:

Do not fully tighten bolts until the table is fully assembled.









Step 1: Secure the bench frame (A) to the bench legs (B), using bolt (D), washer (E), bolt cover (F) and allen key (G). Repeat for the other leg.

\*\*

Step 3: Insert the adjusting knob (H) into the bench leg (B).

B

Allen key (H) and bolt cover (F).

to the bench legs(B), using bolt (D), washer (G),

Use the support bracket(C) to secure the bench frame (A)

Important Notice:

Do not fully tighten bolts until the table is fully assembled.

Step 4: Your bench is now ready for use.