

CEMIX



DIY GUIDES: GP CEMENT



Cemix® New Zealand made General Purpose Cement is a premium Portland cement used in commercial, industrial and residential construction in New Zealand. It fully complies with the requirements of Type GP Cement in New Zealand Standard **NZ3122:2009** TYPE GP – General purpose and blended cement.

TYPICAL APPLICATIONS

Perfect for all kinds of building and construction projects such as paving, foundations, brickwork mortar and fence post footings. Cemix® General Purpose Cement can be used as a binder in a range of applications; Concrete, Mortars, Renders and Grouts. It may also be used in general construction and civil engineering projects.

DIRECTIONS

Cement Mixer



Step One

Measure cement, aggregate and water.

Step Two

Place **2/3** of the water in mixer.

Step Three

Add **1/2** of the measured aggregate.

Step Four

Place all the cement in the mixer.

Step Five

Add the remaining aggregate.

Hand Mixer



Step One

Measure cement, aggregate and water.

Step Two

Thoroughly mix dry ingredients.

Step Three

Make a hollow, then add **2/3** of the water.

Step Four

Mix thoroughly to uniform colour and consistency.

Step Five

Gradually add water and mix until the desired level of consistency is achieved.

Available at
BUNNINGS
warehouse

CEMIX



DIY GUIDES: GP CEMENT

Laying Tips

Placing

It is essential to properly compact the product to attain maximum strength. Compact by rodding, tamping or vibration. A timber edge can be used to screed and level the concrete.

Finishing

Once the concrete has begun to stiffen and the surface is free of excess water, begin the finishing of the product. Avoid over-trowelling as this can lead to surface darkening and colour variations.

Curing

Ensure the product is left to cure for a minimum **7 day** period. Typical methods such as ponding, curing blankets and curing membranes are recommended. The practice of curing will enable concrete to reach its potential strength. It will reduce the potential for plastic cracking and improve surface durability and overall quality i.e. abrasion resistance, impermeability and a reduction in carbonated rate.

Avoid Excess Water

Excess water reduces the strength and durability so it is important to avoid any excess or 'bleed' water on the surface.

TECHNICAL

CONCRETE VOLUMES

Paving Concrete / 12 bags of 20kg bags to make 1.20m³

General Purpose Concrete / 9^{1/2} bags of 20kg bags to make 1.25m³

Bedding Concrete / 8 bags of 20kg bags to make 1.25m³

STRENGTH

3 days / minimum strength of 34MPa

7 days / 46.7MPa

28 days / 63MPa

STANDARD MIX RATIOS

High strength & dense / Cement: 1 Sand: 2 Aggregate: 3

Paths & Floors etc. / Cement: 1 Sand: 2.5 Aggregate: 4

Plaster / Cement: 1 Sand: 3 Aggregate: 0

Mortar / Cement: 1 Sand: 6 Hydrated Lime: 1

